



SYSTEM AIR CONDITIONER

INDOOR UNIT

GH052EAM

GH070EAM


OUTDOOR UNIT

UH052EAMT

UH070EAMT

SERVICE Manual

SYSTEM AIR CONDITIONER



CONTENTS

1. Product Specifications
2. Disassembly and Reassembly
3. Set Up the Model Option
4. Troubleshooting
5. Exploded Views and Parts List
6. Block Diagram
7. Wiring Diagram
8. Schematic Diagram

1. Product Specifications

1-1 Table

MODEL		INDOOR UNIT		GH052EAM	GH070EAM
		OUTDOOR UNIT		UH052EAMT	UH070EAMT
Capacity		Cooling	BTU/hr	18,700	23,900
			Watts	5,500	7,000
		Heating	BTU/hr	20,400	26,300
			Watts	6,000	7,700
Power Supply				1ø, 220~240V~, 50Hz	1ø, 220~240V~, 50Hz
Indoor Unit	Power Input	Cooling	Watts	1,750	2,350
		Heating	Watts	1,800	2,500
	Running Current	Cooling	A	7.7	10.5
		Heating	A	8.0	11.0
	Fan Speed	U-High	r.p.m	-	-
		High	r.p.m	1,315	1,350
		Mid	r.p.m	1,210	1,245
		Low	r.p.m	1,105	1,140
	Air Circulation	High	m³ / min	14	14
		Mid	m³ / min	12	12
		Low	m³ / min	10	10.5
	Noise Level (Sound Pressure)	High	dB(A)	45	46
		Mid	dB(A)	44	45
		Low	dB(A)	43	44
	Heat Exchanger	Type		Slit-fin coil	Slit-fin coil
		Row x Stages x Fin Pitch		2 x 10 x 1.3(580mm)	3 x 10 x 1.5(580mm)
	Fan	Type		Cross Flow Fan	Cross Flow Fan
		Motor Output	W	28	28
	Dimension	H	mm	230	230
		W	mm	918	918
		D	mm	575	575
	Weight	Net / Gross	kg	21 / 25	22 / 26
Outdoor Unit	Fan Speed	High	r.p.m	750	850
		Low	r.p.m	400	340
	Sound Pressure Level		dB(A)	61	61
	Fan	Type		Propeller Fan	Propeller Fan
		Motor Output	W	60	73
	Compressor	Type		Rotary	Rotary
		Model		NN21VBAMT	NN29VACMT
		Motor Output	kW	1.3	1.9
		Protection		Internal	Internal
	Heat Exchanger	Type		Slit-fin coil	Slit-fin coil
		Row x Stages x Fin Pitch		2 x 28 x 1.5	2 x 28 x 1.5
	Refrigerant	Control		EEV	EEV
		Type		R410A	R410A
		Charge	g	1,550	1,650

Table(cont.)





MODEL		INDOOR UNIT		GH052EAM	GH070EAM
		OUTDOOR UNIT		UH052EAMT	UH070EAMT
Outdoor Unit	Dimension	H	mm	648	648
		W	mm	880	880
		D	mm	310	310
	Weight	Net / Gross	kg	67 / 72	69 / 74
Condition	Indoor Unit	Cool(DB/WB)	°C	27 / 19	27 / 19
		Heat(DB/WB)	°C	20 / 15	20 / 15
	Outdoor Unit	Cool(DB/WB)	°C	35 / 24	35 / 24
		Heat(DB/WB)	°C	7 / 6	7 / 6
Piping	Pipe O.D. Size	Liquid	mm(inch)	6.35(1/4")	6.35(1/4")
		Gas	mm(inch)	12.7(1/2")	15.88(5/8")
	Connection Method			Flare	Flare
	Between	Height	m	Max. 15	Max. 15
		Pipe Length	m	Max. 30	Max. 30






Notice : Air Flow rate : Fan Step Control : Low → Mid → High






2. Disassembly and Reassembly






Stop operation of the air conditioner and remove the power cord before repairing the unit.






2-1 Indoor Unit






No	Parts	Procedure	Remark
1	Front Grille – Dust-Collecting Filter	<p>1) Press the "PUSH".</p> <p>2) Front Grille Disassembly (1) Open the Front Grille and pull it up to the direction in the picture.</p> <p>(2) Detach the Safe Ring.</p> <p>3) Filter Disassembly (1) Detach the Filter by disassembling the Grille hook.</p>	   






No	Parts	Procedure	Remark
		<p>4) Detach 6 bolts and 2 fixing screws connected to the Main Body.(Mark point)</p> <p>5) Unscrew a mark point in the picture, and detach the Cover from the Panel with pushing the hook.</p> <p>6) Detach the connection wires of Step Motor and the receive part from the wire of a Main Body.</p> <p>7) Widen the both hooks of panel hooked with the Main Body to both sides, and detach the Panel from the Indoor Unit.</p>	    




No	Parts	Procedure	Remark
2	Electronic Part –Indoor & Outdoor Connecting Cable	<p>1) Unscrew 2 fixing screws of the Case control and screw of Thermistor wire and holder.</p> <p>2) Push the hook, and pull the knob of a case.</p> <p>3) Detach the indoor and outdoor connection wire cable connected to the Terminal.</p> <p>4) Detach the Fan Motor connection wire, Heat Exchanger Sensor connection wire, and the Drain Pump Float S/W connection wire from the connector.</p> <p>5) Detach the Control Box from the main body.</p>	    

No	Parts	Procedure	Remark
3	EVAP ASS'Y	<p>1) Unscrew 3 screws connected to the main body and Cover Side.</p> <p>2) Detach the Cover Side if from the main body.</p> <p>3) Unscrew 16 screws connected to the Drain Pan and the main body.(Mark point)</p> <p>4) Detach the Drain Pan from the main body.</p> <p>5) Unscrew 4 Heat Exchanger screws connected to the cabinet body and cover Evap Guide.</p>	    






No	Parts	Procedure	Remark
		<p>6) Detach the Drain Pump Sensor from the holder, and detach the Heat Exchanger from the main body by pushing it to the direction of Drain.</p>	 
4	Fan & Motor	<p>1) Unscrew 4 screws of Cover Motor and Evap Guide connected to the Case Motor.</p> <p>2) After detaching the Cover Motor by pushing the hook, detach the Cover Evap Guide.</p> <p>3) Detach the Motor and Fan from the case. (Use M3 wrench when detaching the Motor from the Fan.)</p>	  




No	Parts	Procedure	Remark
5	Drain Pump	<p>1) Detach the Drain Hose connected to the Drain Pump by loosening the spring.</p> <p>2) Unscrew 4 screws connected to the Holder Pump and Drain Pump.</p> <p>3) After connector detaching, detach the Drain Pump from the holder.</p>	  
6	Other Parts	<p>1) In case of the other parts, detach it like a picture when necessary.</p>	 



No	Parts	Procedure	Remark
			
7	Front Panel	<ol style="list-style-type: none"> 1) Unscrew 2 screws of the Holder Motor fixed on the Panel, and detach the Holder Motor. The Panel, and detach the Holder Motor. 2) Unscrew 2 screws of the Step-Motor, and detach the Step-Motor from the Panel. 3) Detach the cable clamp screw. 4) Push the hook of case PCB to the both sides and detach the case from the Panel. 	   

No	Parts	Procedure	Remark
		5) When detaching the PCB from the case, unscrew the 6 screws and push the hook at the mark.	
		6) When detaching the blade, detach the opposite side first of Step Motor after turning over the guide on the Panel.	
		7) When detaching the Blade V, after detaching the link by pushing, detach the blade with pushing to the direction of arrow.	

2-2 Outdoor Unit

No	Parts	Procedure	Remark
1	Common Work	<ol style="list-style-type: none"> 1) Loosen the fixing screws and separate the Cover Control. 2) Separate the connection wire from the Terminal Block. 3) Loosen the fixing screws and separate the Upper Cabinet. 4) Loosen the fixing screws and separate the Front Cabinet. 5) Loosen 2 screws and pull up the Control Box. 6) Separate the terminal cover and separate the Comp lead wire. 	    

No	Parts	Procedure	Remark
		7) Loosen the fixing screws and separate the Cabinet Side.	
2	Fan & Motor	<p>1) Loosen the fixing bolt and separate the Fan.</p> <p>2) Loosen 4 fixing bolts to separate the Motor.</p>	 



No	Parts	Procedure	Remark
3	Heat Exchanger & Compressor	<ol style="list-style-type: none">1) Release the refrigerant at first.2) Disassemble the inlet and outlet pipe by welding.3) Loosen the fixing screws of the Heat Exchanger.4) Separate the Heat Exchanger.5) Loosen four bolts of the Compressor.6) Separate the Compressor.	 


3. Set Up the Model Option

3-1 Setting Option Setup Method










































































ex) Option No. : 005115-1 d2340


Step 1 : Enter the Option Setup mode.

- 1st Take out the batteries of remote control.
- 2nd Press the temp.  button simultaneously and insert the battery again.
- 3rd Make sure the remote controller display shown as .



Step 2 : Enter the Option Setup mode and select your option according to the following procedure.

 <p>* Setting is not required if you must  a value which has a  default.</p>	<p>1</p> <p>The default value is  . Otherwise, push the  button to  . Every time you push the button, the display panel reads  or  repeatedly.</p>
	<p>2</p> <p>Push the  button to set the display panel to  . Every time you push the button, the display panel reads  →  →  →  → ... →  →  →  →  →  →  →  repeatedly.</p>
	<p>3</p> <p>Push the  button to set the display panel to  . Every time you push the button, the display panel reads  →  →  →  → ... →  →  →  →  →  →  →  repeatedly.</p>
	<p>4</p> <p>Push the  button to set the display panel to  . Every time you push the button, the display panel reads  →  →  →  → ... →  →  →  →  →  →  →  repeatedly.</p>
	<p>5</p> <p>Push the  button to set the display panel to  . Every time you push the button, the display panel reads  →  →  →  → ... →  →  →  →  →  →  →  repeatedly.</p>
	<p>6</p> <p>Push the  button to set the display panel to  . Every time you push the button, the display panel reads  →  →  →  → ... →  →  →  →  →  →  →  repeatedly.</p>



7 Press button, then the default value is .

8 Push the button to set the display panel to **d** .
Every time you push the button, the display panel reads → **!** → **2** → **3** → ... **9** → **A** → **b** → **c** → **d** → **E** → **F** repeatedly.

9 Push the button to set the display panel to **2** .
Every time you push the button, the display panel reads → **!** → **2** → **3** → ... **9** → **A** → **b** → **c** → **d** → **E** → **F** repeatedly.

10 Push the button to set the display panel to **3** .
Every time you push the button, the display panel reads → **!** → **2** → **3** → ... **9** → **A** → **b** → **c** → **d** → **E** → **F** repeatedly.

11 Push the button to set the display panel to **4** .
Every time you push the button, the display panel reads → **!** → **2** → **3** → ... **9** → **A** → **b** → **c** → **d** → **E** → **F** repeatedly.

12 Push the button to set the display panel to .
Every time you push the button, the display panel reads → **!** → **2** → **3** → ... **9** → **A** → **b** → **c** → **d** → **E** → **F** repeatedly.

* Setting is not required if you must a value which has a default.

Step 3 : Upon completion of the selection, check you made right selections.

Press the Mode Selection key, to set the display part to and check the display part.

→ The display part shows .

Press the Mode Selection key, to set the display part to **!** and check the display part.

→ The display part shows .

Step 4 : Pressing the ON/OFF button ()

When pressing the operation ON/OFF key with the direction of remote controller for unit, the sound "Ding" or "Diring" is heard and the OPERATION ICON() lamp of the display is flickering at the same time, then the input of option is completed. (If the diring sound isn't heard, try again pressing the ON/OFF button.)

Step 5 : Unit operation test-run

First, Remove the battery from the remote controller.

Second, Re-insert the battery into the remote controller.

Third, Press ON/OFF button() with the direction of remote controller for set.

• Error Mode

1st If all lamps of indoor unit are flickering, Plug out, plug in battery again and press ON/OFF key to retry.

2nd If the unit is not working properly or all lamps are continuously flickering after setting the option code, see if the correct option code is set up for its model.

■ OPTION ITEMS





REMOTE CONTROLLER MODEL	SEG1	SEG2	SEG3	SEG4	SEG5	SEG6	SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
GH052EAM	0	2	5	4	4	2	1	A	0	3	7	1
GH070EAM	0	2	5	4	4	2	1	c	0	3	8	2

4. Troubleshooting

■ Detection of errors

- If an error occurs during the operation, one or more LED flickers and the operation is stopped except the LED.
- If you re-operate the air conditioner, it operates normally at first, then detect an error again.

4-1 LED Display on the indoor unit

Abnormal conditions	Indicators					Operating
						
	Green	Red				
Power reset	●	×	×	×	×	
Error of temp. sensor in indoor unit (OPEN/SHORT)	×	×	●	×	×	Displayed on appropriate indoor unit which is operating
Error of heat exchanger sensor in indoor unit	●	×	●	×	×	Displayed on appropriate indoor unit which is operating
Error of outdoor temp. sensor Error of COND sensor Error of DISCHARGE sensor	●	×	×	●	×	Displayed on appropriate indoor unit which is operating Displayed on outdoor unit
1. No communication for 2 minutes between indoor unit and outdoor unit (communication error for more than 2 minutes) 2. Indoor unit receiving the communication error from outdoor unit 3. Outdoor unit tracking 3 minute error 4. When sending the communication error from outdoor unit the mismatching of the communication numbers and installed numbers after completion of tracking.(communication error for more than 2 minutes)	×	×	●	●	×	1. Error of indoor unit: Displayed on the indoor unit regardless of operation 2. Error of outdoor unit: Displayed on the indoor unit which is operating
Communication error between indoor units	●	×	×	×	●	
Self-diagnostic error (including the indoor unit not detected) 1. Error of electronic expansion valve close 2. Error of electronic expansion valve open 3. 2nd detection of high temp. COND 4. 2nd detection of high temp. DISCHARGE 5. Error of reverse phase 6. Compressor down due to 6th detection of freezing	×	×	●	●	●	Displayed on appropriate indoor unit which is operating Displayed on outdoor unit
Error of float switch	×	×	×	●	●	
Error of setting option switches for optional accessories	×	×	●	×	●	
EEPROM error	●	×	●	●	×	
EEPROM option error	●	●	●	●	●	

- If you turn off the air conditioner when the LED is flickering, the LED is also turned off.
- If you re-operate the air conditioner, it operates normally at first, then detect an error again.

● : On ● : Flickering × : Off

4-2 Outdoor Unit

If an error occurs during the operation, it is displayed on the outdoor unit PCB.


Display	Explanation	Remark
$E_r \leftrightarrow P0$	High temp. of Discharge (Protection control)	Error about protection control of outdoor unit
$E_r \leftrightarrow P1$	High temp. of outdoor heat exchanger (Protection control)	
$E_r \leftrightarrow P5$	COMP DOWN to protect being frozen	
$E_r \leftrightarrow P6$	Error of momentary power failure (disappears when the unit is Off/On)	
$E_r \leftrightarrow t1$	Error of OUT TEMP. sensor (OPEN/SHORT)	Errors about outdoor unit sensor (OPEN/SHORT) Detection during the operation of indoor unit (Sensing and sending errors into the communication data)
$E_r \leftrightarrow t2$	Error of temp. sensor in outdoor heat exchanger (OPEN/SHORT)	
$E_r \leftrightarrow t3$	Error of Discharge TEMP. sensor (OPEN/SHORT)	
$E_r \leftrightarrow E1$	System Down caused by communication error after completion of tracking	Communication and indoor unit errors
$E_r \leftrightarrow E2$	Mismatching of the indoor unit numbers set with those communicated after completion of tracking	
$E_r \leftrightarrow E3$	Error of float switch in indoor unit	Self-diagnosis of indoor and outdoor unit (x:indoor unit address)
$E_r \leftrightarrow E5$	Error of setting option switches for optional accessories	
$E_r \leftrightarrow 9x$	OPEN/SHORT error of room sensor in indoor unit	
$E_r \leftrightarrow rx$	OPEN/SHORT error of evap in sensor in indoor unit	
$E_r \leftrightarrow ux$	Error of fan starting	Displays of operating status
$E_r \leftrightarrow G4$	Open error of electronic expansion valve in outdoor unit (Detected once or more times)	
$E_r \leftrightarrow G5$	Close error of electronic expansion valve in outdoor unit (Detected once or more times)	
tU Flicker	Below -5°C when cooling (Outdoor temp.)	
tD Flicker	Over 30°C when heating (Outdoor temp.)	
K1, K2, K3, K4, K5 Flicker	Refer to page 15	

The order of priority : $E1 \rightarrow E2 \rightarrow E4 \rightarrow P0 \rightarrow P1 \rightarrow P5 \rightarrow P6 \rightarrow t1 \rightarrow t2 \rightarrow t3 \rightarrow tu \rightarrow to \rightarrow G4 \rightarrow G5 \rightarrow E3 \rightarrow qx \rightarrow rx \rightarrow vx \rightarrow$

K1, K2, K3, K4, K5

- In case that the same error displays from multi-indoor units, the one having the faster address has the priority.

4-3 Wired remote controller

- If an error occurs,  is displayed on the wired remote controller.
If you would like to see an error code, press the Test button.

Display	Description	Remarks
$E_r \leftrightarrow EA$	Error of communication between the outdoor unit and the wired remote controller	Communication errors
$E_r \leftrightarrow Eb$	Error of communication between the indoor unit and the wired remote controller	
$E_r \leftrightarrow C_x$	Open error of electronic expansion valve	Displays related to indoor unit (x : 0~F)
$E_r \leftrightarrow d_x$	Close error of electronic expansion valve	
$E_r \leftrightarrow o_x$	Error of float switch	
$E_r \leftrightarrow q_x$	OPEN/SHORT error of room sensor in indoor unit	
$E_r \leftrightarrow r_x$	OPEN/SHORT error of eva in sensor in indoor unit	
$E_r \leftrightarrow t_x$	EEPROM error	
$E_r \leftrightarrow U_x$	EEPROM option error	
$E_r \leftrightarrow Eo$	Error of outdoor unit	For the details, refer to the installation manual of the outdoor unit.


The order of priority : EA → Eb → Cx → dx → ox → qx → rx → tx → Ux → Eo

- In case that the same error displays from multi-indoor units, the one having the faster address has the priority.

4-4 Sequence for trouble diagnosis


4-4-1 Outdoor temp. sensor(OPEN/SHORT)

Outdoor unit display	Er → t1 (Outdoor temp. sensor OPEN/SHORT error)
Indoor unit display	● (Operation) × (Timer) ● (Airflow) × (Filter)
How to determine	Disconnection and short of outdoor temp. sensor
Reason of error	Disconnection or leak of applied sensor




4-4-2 Outdoor heat exchanger temp. sensor error(OPEN/SHORT)

Outdoor unit display	Er → t2 (Outdoor heat exchanger temp. sensor error(OPEN/SHORT))
Indoor unit display	● (Operation) × (Timer) ● (Airflow) × (Filter)
How to determine	Disconnection and short of outdoor heat exchanger temp. sensor
Reason of error	Disconnection or leak of Applied sensor





4-4-3 Outdoor discharge temp. sensor error(OPEN/SHORT)

Outdoor unit display	Er → t3 (Outdoor discharge temp. sensor OPEN/SHORT error)
Indoor unit display	● (Operation) × (Timer) ● (Airflow) × (Filter)
How to determine	Disconnection and short of outdoor discharger temp. sensor
Reason of error	Disconnection or leak of Applied sensor




4-4-4 Communication error during the operation

Outdoor unit display	Er → E1 (Communication error during the operation)
Indoor unit display	× (Operation) ● (Timer) ● (Airflow) × (Filter)
How to determine	Disconnection and short of communication lines
Reason of error	Communication error between the indoor unit and outdoor unit.




4-4-5 Communication error between indoor and outdoor after initial power input.

Outdoor unit display	Er → E2 (Tracking error)
Indoor unit display	× (Operation) ● (Timer) ● (Airflow) × (Filter)
How to determine	Mismatching the communicating indoor unit and setting switch indoor numbers When outdoor tracking
Reason of error	Communication error between the indoor unit and outdoor unit, and installation number switch setting miss



4-4-6 Indoor float switching error


Outdoor unit display	Er → E3 (Indoor float switching error)
Indoor unit display	× (Operation) × (Timer) ● (Airflow) ● (Filter)
How to determine	The status continues over 1 minute that indoor unit float switch is opened.
Reason of error	The rising of water level of drain pan due to the disorder of indoor unit drain pump, the badness of detection sensor



*** Note : E3 error should be released when indoor unit power is reset.**

5. Exploded Views and Parts List

5-1 Indoor Unit




You can search for the updated part code number through the ITSELF.
URL : <http://itself.sec.samsung.co.kr>

■ Parts List

No.	Code No.	Description	Specification	Q'TY	
				GH052EAM	GH070EAM
1	DB93-01811A	ASS'Y CONTROL BOX IN	ASS'Y	1	1
1-1	DB61-01482A	CASE CONTROL	PS(V0), BLK	1	1
1-2	DB61-01236A	BASE TERMINAL	SGCC-M	1	1
1-3	DB93-01480A	ASS'Y MAIN PCB	ASS'Y PCB	1	1
1-4	DB93-01481A	SUB PCB	PCB	1	1
1-5	DB26-10065B	TRANS POWER		1	1
1-6	DB93-01783A	ASS'Y TERMINAL BLOCK 4P	DAF 4P	1	1
1-7	DB93-01784A	ASS'Y TERMINAL BLOCK 6P	DAF S6P	1	1
1-8	DB61-00250A	CLAMP WIRE	NY	2	2
2	DB63-00779A	COVER CONTROL	HIPS	1	1
3	DB91-00232A	ASS'Y DRAIN PAN	ASS'Y DRAIN	1	1
3-1	DB63-00062A	RUBBER DRAIN CAP	NBR	1	1
3-2	DB71-50025A	WIRE HOLDER	NY	1	1
4	DB63-00672A	COVER SIDE LF	PP(INCOMBUSTIBLE), BLK	1	1
5	DB96-02754A	ASS'Y EVAP	FP 1.5 SLIT 3x10	-	1
	DB96-03496A	ASS'Y EVAP	FP 1.3 SLIT 2x10	1	-
5-1	DB96-02753A	ASS'Y TUBE COLLECTOR	12.7ø	-	1
	DB96-03325A	ASS'Y TUBE COLLECTOR	9.52ø	1	-
5-2	DB96-02752A	ASS'Y INLETPART	6.35ø CAPI 2.0ø	-	1
	DB96-03324A	ASS'Y INLETPART	6.35ø CAPI 2.0ø	1	-
6	DB94-00040S	ASS'Y C-F-FAN	ø95 8 ranks, AS+G/F 20%	2	2
7	DB31-00241A	MOTOR ASSY	PFS040AVEB	2	2
8	DB90-01182A	ASS'Y COVER MOTOR	HIPS, INSU	2	2
9	DB90-01184A	ASS'Y CASE MOTOR	HIPS, INSU	2	2
10	DB95-00131F	ASS'Y SENSOR FLOAT		2	2
11	DB90-01183A	ASS'Y COVER EVAP GUIDE	HIPS, INSU	2	2
12	DB90-01185A	ASS'Y CASE FAN SIDE SUB	HIPS, INSU	2	2
13	DB94-00066A	ASS'Y BEARING	BEARING	2	2
14	DB61-01475A	GUIDE CONTROL	HIPS	1	1
15	DB31-00207A	DRAIN PUMP	KS1003SAC	1	1
16	DB61-01293A	HOLDER DRAIN PUMP	HIPS	1	1
17	DB73-00022B	RUBBER DRAIN PUMP	HIPS(HB), BLK	4	4
18	DB94-00371A	ASS'Y DRAIN SOCKET	ASS'Y	1	1
19	DB69-00137A	BAND RING	STS304	1	1
20	DB69-00695A	CUSHION BODY	EPS(GRY)	2	2
21	DB61-01468A	CLIP BRUSH	EPS(GRY)	4	4
22	DB64-00778A	CABINET BASE	SGCC-M 0.7T	1	1
23	DB64-00781A	CABI SIDE RH	SGCC-M 0.7T	1	1
24	DB64-00780A	CABI SIDE LF	SGCC-M 0.7T	1	1
25	DB61-00712A	HOLDER CABI SIDE	SGCC-M 1.0T	4	4


5-2 Panel



■ Parts List

No.	Code No.	Description	Specification	Q'TY		
				PG103M	PG103M1	PG103M2
1	DB64-00777A	PANEL FRONT	ABS	1	1	1
2	DB64-00775A	GRILLE FRONT	ABS	1	1	1
3	DB64-00774A	FILTER INLET AIR	ASS'Y	2	2	2
4	DB61-01297A	CASE OUTLET AIR	HIPS	2	2	2
5	DB66-00415A	BLADE H	HIPS	2	2	2
6	DB66-00402A	BLADE V	PP	16	16	16
7	DB66-00416A	LINK BLADE V	PP	4	4	4
8	DB66-00755A	LATCH DC	ASS'Y	3	3	3
9	DB63-00676A	COVER PANEL	HIPS	1	1	1
10	DB70-00031A	PLATE HANGER	STS304	2	2	2
11	DB31-10153D	MOTOR STEP	ASS'Y	2	2	2
12	DB61-00535A	HOLDER MOTOR	HIPS V0 BLK	2	2	2
13	DB39-00874C	C/W MOTOR STEP LONG	UL1007	1	1	1
14	DB39-00874B	C/W MOTOR STEP SHORT	UL1007	1	1	1
15	DB93-01666A	PCB DISPLAY		1	1	1
16	DB39-00875A	C/W DISPLAY	UL1007	1	1	1
17	DB64-00745A	INLAY WINDOW	PC	1	1	1
18	DB64-00746A	INLAY BUTTON	ABS	1	1	1
19	DB61-01238A	CASE LED PCB	ABS	1	1	1
20	-	CABLE CLAMP	4N	2	2	2
21	DB97-00871D	ASS'Y WIRED REMOCON	WIRED	-	1	-
22	DB97-00387F	ASS'Y WIRELESS REMOCON	WIRELESS	-	-	1


5-3 Outdoor Unit



■ Parts List

No.	Code No.	Description	Specification	Q'TY	
				UH052EAMT	UH070EAMT
1	DB90-01363A	ASS'Y-COVER TOP	ASS'Y	1	1
2	DB90-01388A	ASS'Y CABINET-FRONT	ASS'Y	1	1
3	DB67-00140A	FAN-PROPELLER	AS+GF20%,OD460,3BLADE	1	1
4	DB61-01167A	BRACKET-MOTOR	SGCC-M,T1.6	1	1
5	DB90-00940B	ASS'Y-PARTITION	ASS'Y	1	1
6	DB95-00455A	ASS'Y COMP	SIAM,NN29VACMT	-	1
	DB95-00454A	ASS'Y COMP	SIAM,NN21VBAMT	1	-
7	DB95-30013T	ASS'Y HEATER COMP	40W	1	1
8	DB31-00216A	MOTOR-FAN	OSEM-886SRC(S509)	-	1
	DB31-00027G	MOTOR-FAN	OSEM-906SRC(S507)	1	-
9	DB93-02410A	ASS'Y CONTROL OUT	ASS'Y	-	1
	DB93-02410B	ASS'Y CONTROL OUT	ASS'Y	1	-
9-1	DB26-10070A	TRANS-POWER	AC230V,DC17V	1	1
9-2	DB65-00112A	TERMINAL BLOCK-6P	35A 4P,25A 2P	1	1
9-3	3501-001204	RELAY POWER	MUF20CF,2A	1	1
9-4	DB61-30625A	BRACKET-TERMINAL	SGCC-M	1	1
9-5	DB93-40264E	ASS'Y CONTROL BOX OUT	ASS'Y	1	1
9-6	DB61-00152A	CASE-PCB-OUT	T2.5,ABS,BLK	1	1
9-7	2301-001369	C-FILM	3uF/450VAC	1	1
10	2501-001236	C-OIL	30uF/450VAC	-	1
	2501-001235	C-OIL	25uF/450VAC	-	1
	2501-001240	C-OIL	50uF/450VAC	1	-
11	DB32-00021F	THERMISTOR	AWG22,L470,L550	1	1
12	DB32-00071C	THERMISTOR	AWG22,L600	1	1
13	DB61-01685A	BRACKET-CAPACITOR	SGCC-M	-	1
	DB69-60008A	BAND-CAPACITOR	SGCC-M	1	-
14	DB93-01855K	ASS'Y PCB MAIN	CEILING OUTDOOR PCB	1	-
	DB93-01855J	ASS'Y PCB MAIN	CEILING OUTDOOR PCB	-	1
15	DB90-40176D	ASS'Y COVER CONTROL	ASS'Y	1	1
16	DB90-01189B	ASS'Y-ASS'Y CABI SIDE RH	ASS'Y	1	1
17	DB62-01471A	INSULATION-CLOTH COMP	UH070EAMT	-	1
	DB62-02295A	INSULATION-CLOTH COMP	UH052EAMT	1	-
18	DB96-02876A	ASS'Y 4WAY VALVE	ASS'Y	-	1
	DB96-02877A	ASS'Y 4WAY VALVE	ASS'Y	1	-
19	DB96-02896A	ASS'Y EEV VALVE	ASS'Y	-	1
	DB96-02896B	ASS'Y EEV VALVE	ASS'Y	1	-
20	DB63-00613A	GUARD-COND	SECC-P,T1.6	1	1
21	DB61-01221A	GUIDE-SCREEN	P.E.H 100%,T2.5,1015x615,BLK	1	1
22	DB63-00320A	GUARD-FAN	HSWR,460	1	1
23	DB96-02849A	ASS'Y COND UNIT	UH070EAMT,UH052EAMT	1	1
24	DB96-02936A	ASS'Y COLLECTOR IN	ASS'Y	1	1
25	DB96-02937A	ASS'Y COLLECTOR OUT	ASS'Y	1	1
26	DB90-01291A	ASS'Y CABINET BASE OUT	ASS'Y	1	1


6. Block Diagram



- 485 comm applied, room temp. compensation
- EEPROM option saving and blackout restoring function
- Left and right FAN MOTOR phase control
- Power-comm line misconnection prevention function
- Cost saving related sub-option separation between indoor unit communication part
- Option part sub-development according to the SVC structure

7. Wiring Diagram


7-1 Indoor Unit



This Document can not be used without Samsung's authorization.


7-2 Outdoor Unit

■ UH052EAMT



This Document can not be used without Samsung's authorization.

■ UH070EAMT




Code No : DB98-14410B

This Document can not be used without Samsung's authorization.

8. Schematic Diagram


8-1 Indoor Unit




This Document can not be used without Samsung's authorization.

8-2 Outdoor Unit

■ UH052EAMT



This Document can not be used without Samsung's authorization.





This Service Manual is a property of Samsung Electronics Co., Ltd.
Any unauthorized use of Manual can be punished under applicable
International and/or domestic law.

© Samsung Electronics Co., Ltd. Feb. 2004.
Printed in Korea.
Code No. DB98-16284A(1)